

MOUNTING PROCEDURE**KIT ENGINE SPOILER
DUCATI MONSTER 696****DN7 PUNTALE**WWW.BARRACUDAMOTO.COM**BRACKET 1:**

RIGHT SIDE - THICKNESS MM 10 + SCREW 6X45;
REMOVE THE CARTER SCREW AND MOUNT THE SPECIFIC BRACKET
USING THE 6X45 SCREW AND THE THICKNESS HIGH 10 MM

BRACKET 2:

RIGHT SIDE;
REMOVE THE CARTER SCREW AND MOUNT THE SPECIFIC BRACKET
USING THE REMOVED SCREW

BRACKET 3:

LEFT SIDE - THICKNESS MM10 + SCREW 6X45;
REMOVE THE CARTER SCREW AND MOUNT THE SPECIFIC BRACKET
USING THE 6X45 SCREW AND THE THICKNESS H 10MM

BRACKET 4:

LEFT SIDE , NEAR THE PADDOCK STAND;
REMOVE THE CARTER SCREW AND MOUNT THE SPECIFIC BRACKET
USING THE REMOVED SCREW

MOUNT THE THICKNESS H 10 IN CORRESPONDENCE TO THE BRACKET 1 USING THE 5X30 SCREW, USE THE RUBBER WASHER BETWEEN THE THICKNESS AND THE ENGINE SPOILER.

MOUNT THE ENGINE SPOILER INSTALLING ALL THE 5X16 AND 5X30 SCREWS AND DON'T LOCK. PROCEED TO LOCK AFTER PUT THE ENGINE SPOILER IN THE RIGHT POSITION.

KIT

- X4. BRACKET
- X1. BARRACUDA ENGINE SPOILER
- X2. THICKNESS DIAMETER 10
- X2. "CYLINDRICAL HEAD" SCREW 6X45
- X3. SCREW 5X16
- X1. SCREW 5X30
- X4. WASHER DIAMETER 5
- X4. RUBBER WASHER
- X1. THICKNESS HIGH 10 MM



DON'T LOCK THE SCREWS OF BRACKETS, ONCE YOU MOUNT APPROACH THE ENGINE SPOILER ALREADY MOUNTED AND ADJUST THE BRACKET POSITION: MOUNT THE SCREWS TO THE INSTALLATION OF ENGINE SPOILER USING THE THICKNESS H 10 MM BETWEEN THE BRACKET 1 AND THE ENGINE SPOILER; MOUN ALL THE SCREWS USING THE RUBBER WASHERS BETWEEN THE BRACKET AND THE ENGINE SPOILER DUE THE VIBRATIONS. PUT THE Ø 5 WASHERS BETWEEN THE HEAD OF SCREW AND THE ENGINE SPOILER. MOUNT ALL THE SCREWS WITHOUT LOCKING TOO MUCH, ADJUST THE POSITIONS AND THAN LOCK ALL.

ATTENTION: ADJUST THE POSITION OF ENGINE SPOILER MAINTAINING IN THE DISTANCE TO THE COLLECTORS