

## ASSEMBLING INSTRUCTION

### WINDSHIELD KIT

### HG3300-26C

WWW.BARRACUDAMOTO.COM

## LEGEND

- |  |  |   |
|--|--|---|
| 1. KNURLED NUT<br>DADO ZIGRINATO<br>TUERCA MOLETEADA<br>GERÄNDELTE MUTTER<br>ECROU MOLETÉ                        | 4. TB SCREW M5X18<br>VITE TB M5X18<br>TORNILLO TB M5X18<br>TB SCHRAUBE M5X18<br>VIS TB M5X18                   | 7. TB SCREW M5X14<br>VITE TB M5X14<br>TORNILLO TB M5X14<br>TB SCHRAUBE M5X14<br>VIS TB M5X14                        |
| 2. SPECIFIC BRACKETS<br>STAFF SPECIFICHE<br>SOPORTES ESPECÍFICOS<br>SPEZIFISCHE KLAMMERN<br>SUPPORTS SPÉCIFIQUES | 5. RUBBER WASHERS<br>RONDELLA GOMMA<br>ARANDELAS DE CAUCHO<br>GUMMISCHEIBE<br>RONDELLE EN CAOUTCHOUC           | 8. TEFLON WASHERS Ø5<br>RONDELLA TEFLON Ø5<br>ARANDELAS DE TEFLON Ø5<br>TEFLONSCHIEBE Ø5<br>RONDELLE EN TÉFLON Ø5   |
| 3. TB SCREW M5X10<br>VITE TB M5X10<br>TORNILLO TB M5X10<br>TB SCHRAUBE M5X10<br>VIS TB M5X10                     | 6. LARGE WASHER Ø5<br>RONDELLA LARGA Ø5<br>ARANDELA ANCHA Ø5<br>BREITE UNTERLEGSCHIEBE Ø5<br>RONDELLE LARGE Ø5 | 9. SELF-LOCKING NUT<br>DADO AUTOBLOCCANTE<br>TUERCA AUTOBLOQUEANTES<br>SELBSTSICHERNDE MUTTER<br>ECROU AUTOBLOQUANT |

