

## MOUNTING PROCEDURE

KIT SAVE CARTER  
SUZUKI GSXR 600/750 '11 - '13

**SP6101-11**

WWW.BARRACUDAMOTO.COM

## KIT

- X2. PVC HEAD
- X1. SCREW 10X55 (RIGHT)
- X1. SCREW 10X80 (LEFT)
- X2. SAVE CARTER BASE DIAMETER 10
- X1. BOLT 10X70 (RIGHT)
- X1. BOLT 10X50 (LEFT)
- X1. SPACER H 20 (RIGHT)
- X1. SPACER H 45 (LEFT)
- X2. SPACER H 6
- X2. NUT DIAMETER 10
- X1. SPACER H 8
- X1. BUSH DIAMETER 6X30
- X1. WASHER DIAMETER 6 LARGE
- X2. SPECIFIC BRACKET

### STEP 1

Bolt 10X70 (Right)  
Bolt 10X50 (Left)

Spacer h 6

Bolt 10X55 (Right)  
Bolt 10X80 (Left)

Spacer h 20 (Right)  
Spacer h 45 (Left)

Save carter base

Nut Ø 10

### STEP 2 (ONLY RIGHT SIDE)

REPLACE THE BUSH THAT FIX THE BOTTOM WITH THE ONE YOU FIND IN THE KIT (6X30). PUT THE SPACER H. 8, IN CONTRAST BETWEEN THE BOTTOM AND THE CHASSIS TO MAKE THE RIGHT DISTANCE THE BOTTOM

