

ASSEMBLING INSTRUCTION**WINDSHIELD****ZDS300-18****WWW.BARRACUDAMOTO.COM****LEGEND**

- | | |
|---|---|
| 1. LICENCE PLATE
PORTATARGA
PLACA
NUMMERNSCHILD
PLAQUE D'IMMATRICULATION | 4. TEFLON WASHER
RONDELLA DI TEFLON
ARANDELA DE TEFLON
TEFLON SCHEIBE
RONDELLE EN TEFLON |
| 2. ALLEN SCREW M5X25
VITE A BRUGOLA M5X25
TORNILLO ALLEN M5X25
INBUSSCHRAUBE M5X25
VIS ALLEN M5X25 | 5. RUBBER WASHER
RONDELLA DI GOMMA
ARANDELA DE GOMA
GUMMISCHEIBE
RONDELLE EN CAOUTCHOUC |
| 3. ALLEN SCREW M5X16
VITE A BRUGOLA M5X16
TORNILLO ALLEN M5X16
INBUSSCHRAUBE M5X16
VIS ALLEN M5X16 | 6. THREADED THICKNESSES
SPESORE FILETTATO
ESPACIADOR ROSCADO
GEWINDE ABSTAND
ESPACEUR FILETÉ |

