



MOUNTING PROCEDURE

KIT WINDSHIELD YAMAHA MT07

YMT7300

WWW.BARRACUDAMOTO.COM

MOUNTING PROCEDURE:

REMOVE THE ORIGINAL SCREWS AND FIX THE SPECIFIC BRACKET WITH THE SCREW 6X30

POSITION ALL LIKE SHOWN IN THE PICTURE.

FIND THE RIGHT POSITION OF WINDSHIELD ON THE BRACKET ALREADY FIXED AND LOCK ALL THE SCREWS.

KIT

- X1. PLEXIGLASS
- X2. SPECIFIC BRACKET
- X4. SPECIAL WASHER
- X4. ROUND HEAD SCREW 5X12
- X4. ROUND HEAD SCREW 6X30
- X4. TEFLON WASHER Ø 5
- X4. RUBBER WASHER

FIXING ON MOTORBIKE

FIXING OF WINDSHIELD

Screw 6x30

Special washer

Specific Bracket

Plexiglass

Rubber washer

Teflon washer

Screw 5x12

